

digitalSTROM Light Functional State Machine

digitalSTROM

Version: v1.4-branch*

May 22, 2017

*Revision: 6d0a8b6a9a98d5874ebfa542a78ea62bf3c04f8d

©2017 digitalSTROM AG. All rights reserved.

The digitalSTROM logo is a trademark of the digitalSTROM. Use of this logo for commercial purposes without the prior written consent of digitalSTROM may constitute trademark infringement and unfair competition in violation of international laws.

No licenses, express or implied, are granted with respect to any of the technology described in this document. digitalSTROM retains all intellectual property rights associated with the technology described in this document. This document is intended to assist developers to develop applications that use or integrate digitalSTROM technologies.

Every effort has been made to ensure that the information in this document is accurate. digitalSTROM is not responsible for typographical errors.

digitalSTROM AG
Building Technology Park Zürich
Brandstrasse 33
CH-8952 Schlieren
Switzerland

Even though digitalSTROM has reviewed this document, digitalSTROM MAKES NO WARRANTY OR REPRESENTATION, EITHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT, ITS QUALITY, ACCURACY, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE. AS A RESULT THIS DOCUMENT IS PROVIDED "AS IS", AND YOU, THE READER ARE ASSUMING THE ENTIRE RISK AS TO ITS QUALITY AND ACCURACY.

IN NO EVENT WILL DIGITALSTROM BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY DEFECT OR INACCURACY IN THIS DOCUMENT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, ORAL OR WRITTEN, EXPRESS OR IMPLIED. NO DIGITALSTROM AGENT OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENSION, OR ADDITION TO THIS WARRANTY.

Contents

1	Introduction	5
1.1	Operation Principles	5
1.2	How to Read	5
1.2.1	Specialties for Zone-Button Events	6
1.3	Zone States	6
1.4	Area States	6
1.5	Actions	6
1.5.1	Zone Actions	6
1.5.2	Area Actions	7
1.6	Defaults	7
2	State Machine Tables	8
2.1	Pushbutton Actions	8
2.1.1	Zone-Button: CLICK_1X/TIP_1X	8
2.1.2	Zone-Button: CLICK_1X_UP/TIP_1X_UP	9
2.1.3	Zone-Button: CLICK_1X_DOWN/TIP_1X_DOWN	10
2.1.4	Zone-Button: CLICK_2X/TIP_2X/CLICK_2X_UP/TIP_2X_UP	11
2.1.5	Zone-Button: CLICK_2X_DOWN/TIP_2X_DOWN	12
2.1.6	Zone-Button: CLICK_3X/TIP_3X/CLICK_3X_UP/TIP_3X_UP	13
2.1.7	Zone-Button: CLICK_3X_DOWN	14
2.1.8	Zone-Button: TIP_3X_DOWN	15
2.1.9	Zone-Button: TIP_4X/TIP_4X_UP	16
2.1.10	Zone-Button: TIP_4X_DOWN	17
2.1.11	Zone-Button: HOLD_START/HOLD_REPEAT	18
2.1.12	Zone-Button: HOLD_START_UP/HOLD_REPEAT_UP	19
2.1.13	Zone-Button: HOLD_START_DOWN/HOLD_REPEAT_DOWN	20
2.1.14	Area-Button (with LocalPrio): CLICK_1X/TIP_1X	21
2.1.15	Area-Button (with LocalPrio): CLICK_1X_UP/TIP_1X_UP	22
2.1.16	Area-Button: CLICK_1X_DOWN/TIP_1X_DOWN	23
2.1.17	Area-Button: CLICK_2X/TIP_2X	24
2.1.18	Area-Button: CLICK_2X_UP/TIP_2X_UP	25
2.1.19	Area-Button: CLICK_2X_DOWN/TIP_2X_DOWN	26
2.1.20	Area-Button: CLICK_3X/TIP_3X	27
2.1.21	Area-Button: CLICK_3X_UP/TIP_3X_UP	28
2.1.22	Area-Button: CLICK_3X_DOWN	29
2.1.23	Area-Button: TIP_3X_DOWN	30
2.1.24	Area-Button: TIP_4X	31
2.1.25	Area-Button: TIP_4X_UP	32
2.1.26	Area-Button: TIP_4X_DOWN	33
2.1.27	Area-Button: HOLD_START/HOLD_REPEAT	34
2.1.28	Area-Button: HOLD_START_UP/HOLD_REPEAT_UP	35
2.1.29	Area-Button: HOLD_START_DOWN/HOLD_REPEAT_DOWN	36
2.1.30	Local Prio timeout	37
2.1.31	Area-Button (no LocalPrio): CLICK_1X/TIP_1X	38
2.1.32	Area-Button (no LocalPrio): CLICK_1X_UP/TIP_1X_UP	39

2.2	State Transitions	40
2.2.1	CALL_SCENE(S0)	40
2.2.2	CALL_SCENE(S1-S4)	41
2.2.3	STOP	42
2.2.4	CALL_SCENE(A0)	43
2.2.5	CALL_SCENE(A1)	44
2.2.6	STOP_AREA	45
2.2.7	CALL_SCENE_FORCE(S0) CALL_SCENE(STANDBY) CALL_SCENE(DEEP_OFF)	46
2.2.8	CALL_SCENE_FORCE(S1-S4)	47
2.2.9	CALL_SCENE_FORCE(A0)	48
2.2.10	CALL_SCENE_FORCE(A1)	49
2.2.11	SET_LOCAL_PRIO(A1)	50
2.2.12	DIMM_ZONE	51
2.2.13	DIMM_AREA	52
2.2.14	CALL_SCENE_MIN(S1-S4)	53
2.2.15	CALL_SCENE_MIN(A1)	54
2.2.16	STOP timeout/(stop timer)	55
2.2.17	{start LP timer}	56

Introduction

Operation Principles

The concrete tables in section 2 are derived from a number of basic operation principles:

- Single button pushes on one-way buttons toggle the zone.
- Single button pushes on two-way buttons select “on” (up button) and “off” (down button) scenes
- Multiple button pushes in short succession select different scenes.
- Holding a button gradually changes the setting (stepping/dimming).
- If state transitions (RUNNING->) requires significant time a button action during the transition stops the transition.
- Areas work like Local Push Buttons, just with multiple devices.
- Areas that are not operated directly follow the zone: e.g. if the zone is turned-on the area is in an ‘on’-state (ZONE_ON) as well.

How to Read

Each table in subsection 2.1 contains the action(s) triggered by a push button event. The events are categorized by the type of the push button: Zone-Button or Area-Button (with or without Local Priority). If there is no mention of LocalPriority on an Area-Button, the same actions happen independent of Local Priority.

The left part of the table under the heading “Origin” shows all possible combinations of states of the whole zone and one of its contained areas. The right part of the table shows the action to be executed.

Each table in subsection 2.2 shows the resulting states for zone and area (“Destination”) after a specific action is executed.

If an event triggers multiple actions the state transitions for all actions have to be chained: “Initial State” → “Action 1” → “Intermediate State” → “Action 2” → “Final State”.

Example: What happens when a zone pushbutton is clicked twice in a turned-off zone?

1. Find the table for CLICK_2X of a zone pushbutton → subsubsection 2.1.4
2. Select the origin states in the table → Zone: OFF; Area: OFF
3. The resulting action is CALL_SCENE(S2)
4. Find the table for CALL_SCENE(S2) → subsubsection 2.2.2
5. Select the origin states in the table → Zone: OFF; Area: OFF
6. The resulting state is Zone: RUNNING->ON; Area: ZONE_ON
7. Because the default running time in the light state machine is 0 seconds the final state is Zone: ON; Area: ZONE_ON

Now what happens if one pushes an area button in this zone?

1. Find the table for CLICK_1X of an area pushbutton → because Local Priority is enabled by default in the light state machine: subsubsection 2.1.14
2. Select the origin states in the table → Zone: ON; Area: ZONE_ON
3. The resulting action is CALL_SCENE(A0)
4. Find the table for CALL_SCENE(A0) → subsubsection 2.2.4

5. The resulting state is Zone: ON; Area: RUNNING->OFF
6. Because the default running time in the light state machine is 0 seconds the final state is Zone: ON; Area: OFF

Specialties for Zone-Button Events

Each zone contains four areas. All areas are reacting to zone actions too. Therefore when a zone pushbutton triggers area actions in one or multiple areas as well as zone actions, up to four state transitions with associated actions actually happen. All the area actions are performed before the zone actions (except STOP, it is executed first in any case).

Zone States

OFF Zone is turned off.

ON Zone is turned on.

RUNNING->X Zone is in process to X.

Area States

OFF Area is turned off.

ZONE_ON Area is on because the zone was turned on.

ON Area is turned on explicitly, but still reacting to zone commands.

ON (PRIO) Area is turned on explicitly and local priority is pending.

PRIO ON Area is turned on explicitly and not reacting to zone commands.

RUNNING->X Area is in process to X.

Actions

Zone Actions

CALL_SCENE(S0-S4) Execute a scene command. Depending on the configuration of the device sending the event the Preset 0...4, Preset 10...14, Preset 20...24, Preset 30...34 or Preset 40...44 scenes are executed.

CALL_SCENE_FORCE(S0-S4) Execute a scene command and overwrite any Local Priorities. Depending on the configuration of the device sending the event the Preset 0...4, Preset 10...14, Preset 20...24, Preset 30...34 or Preset 40...44 scenes are executed.

ZONE_OFF after 1 s: execute CALL_SCENE_FORCE(S0) scene command on the group; after 2 s: execute the STANDBY scene command on all groups; after 3 s: execute the DEEP_OFF scene command on all groups.

DIMM_ZONE Stepping commands are executed every 250 ms in the zone/area as long as the HOLD_REPEAT events arrive every second and there is no HOLD_END event.

CALL_SCENE_MIN Start stepping from off.

(stop timer) (internal action) stop the “RUNNING->” timer.

Area Actions

CALL_SCENE(A0-A1) Depending of the area the Area 1, Area 2, Area 3 or Area 4 scene commands are executed.

SET_LOCAL_PRIO Activate Local Priority mode for the previously called area scene.

DIMM_AREA Stepping scene commands are executed every 250 ms in the zone/area as long as the HOLD_REPEAT events arrive every second and there is no HOLD_END event.

AREA_STOP Execute the STOP scene command in the area and stop the internal area timer.

(start LP timer) (internal action) Start a 2 s timer to schedule the “ON (PRIO)” to “ON PRIO” transition.

(stop timer) (internal action) stop the “RUNNING->” timer.

Defaults

The **RUNNING->X** timer is 0 by default. Therefore all **RUNNING->X** states are equal to **X**.

All Area-Buttons use Local Priority by default.

State Machine Tables

Pushbutton Actions

Zone-Button: CLICK_1X/TIP_1X

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S1)
OFF	ON	CALL_SCENE(S1)
OFF	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S1)
OFF	PRIORITY ON	CALL_SCENE(S1)
OFF	RUNNING->PRIORITY ON	STOP
OFF	RUNNING->OFF	STOP
OFF	RUNNING->ON	STOP
OFF	RUNNING->ON (PRIO)	STOP
ON	OFF	CALL_SCENE(S0)
ON	ZONE_ON	CALL_SCENE(S0)
ON	ON	CALL_SCENE(S0)
ON	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S0)
ON	PRIORITY ON	CALL_SCENE(S0)
ON	RUNNING->PRIORITY ON	STOP
ON	ZONE_ON	CALL_SCENE(S0)
ON	RUNNING->OFF	STOP
ON	RUNNING->ON	STOP
ON	RUNNING->ON (PRIO)	STOP
RUNNING->OFF	OFF	STOP
RUNNING->OFF	PRIORITY ON	STOP
RUNNING->ON	PRIORITY ON	STOP
RUNNING->ON	ZONE_ON	STOP

Zone-Button: CLICK_1X_UP/TIP_1X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S1)
OFF	ON	CALL_SCENE(S1)
OFF	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S1)
OFF	PRIORITY ON	CALL_SCENE(S1)
OFF	RUNNING->PRIORITY ON	STOP
OFF	RUNNING->OFF	STOP
OFF	RUNNING->ON	STOP
OFF	RUNNING->ON (PRIO)	STOP
ON	OFF	CALL_SCENE(S1)
ON	ZONE_ON	CALL_SCENE(S1)
ON	ON	CALL_SCENE(S1)
ON	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S1)
ON	PRIORITY ON	CALL_SCENE(S1)
ON	RUNNING->PRIORITY ON	STOP
ON	ZONE_ON	CALL_SCENE(S1)
ON	RUNNING->OFF	STOP
ON	RUNNING->ON	STOP
ON	RUNNING->ON (PRIO)	STOP
RUNNING->OFF	OFF	STOP
RUNNING->OFF	PRIORITY ON	STOP
RUNNING->ON	PRIORITY ON	STOP
RUNNING->ON	ZONE_ON	STOP

Zone-Button: CLICK_1X_DOWN/TIP_1X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S0)
OFF	ON	CALL_SCENE(S0)
OFF	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S0)
OFF	PRIORITY ON	CALL_SCENE(S0)
OFF	RUNNING->PRIORITY ON	STOP
OFF	RUNNING->OFF	STOP
OFF	RUNNING->ON	STOP
OFF	RUNNING->ON (PRIO)	STOP
ON	OFF	CALL_SCENE(S0)
ON	ZONE_ON	CALL_SCENE(S0)
ON	ON	CALL_SCENE(S0)
ON	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S0)
ON	PRIORITY ON	CALL_SCENE(S0)
ON	RUNNING->PRIORITY ON	STOP
ON	ZONE_ON	CALL_SCENE(S0)
ON	RUNNING->OFF	STOP
ON	RUNNING->ON	STOP
ON	RUNNING->ON (PRIO)	STOP
RUNNING->OFF	OFF	STOP
RUNNING->OFF	PRIORITY ON	STOP
RUNNING->ON	PRIORITY ON	STOP
RUNNING->ON	ZONE_ON	STOP

Zone-Button:

CLICK_2X/TIP_2X/CLICK_2X_UP/TIP_2X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S2)
OFF	ON	CALL_SCENE(S2)
OFF	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S2)
OFF	PRI0 ON	CALL_SCENE(S2)
OFF	RUNNING->PRI0 ON	STOP, CALL_SCENE(S2)
OFF	RUNNING->OFF	STOP, CALL_SCENE(S2)
OFF	RUNNING->ON	STOP, CALL_SCENE(S2)
OFF	RUNNING->ON (PRIO)	STOP, SET_LOCAL_PRIO, CALL_SCENE(S2)
ON	OFF	CALL_SCENE(S2)
ON	ZONE_ON	CALL_SCENE(S2)
ON	ON	CALL_SCENE(S2)
ON	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S2)
ON	PRI0 ON	CALL_SCENE(S2)
ON	RUNNING->PRI0 ON	STOP, CALL_SCENE(S2)
ON	ZONE_ON	CALL_SCENE(S2)
ON	RUNNING->OFF	STOP, CALL_SCENE(S2)
ON	RUNNING->ON	STOP, CALL_SCENE(S2)
ON	RUNNING->ON (PRIO)	STOP, SET_LOCAL_PRIO, CALL_SCENE(S2)
RUNNING->OFF	OFF	CALL_SCENE(S2)
RUNNING->OFF	PRI0 ON	CALL_SCENE(S2)
RUNNING->ON	PRI0 ON	CALL_SCENE(S2)
RUNNING->ON	ZONE_ON	CALL_SCENE(S2)

Zone-Button: CLICK_2X_DOWN/TIP_2X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE_FORCE(S0)
OFF	ON	CALL_SCENE_FORCE(S0)
OFF	ON (PRIO)	CALL_SCENE_FORCE(S0)
OFF	PRIORITY ON	CALL_SCENE_FORCE(S0)
OFF	RUNNING->PRIORITY ON	CALL_SCENE_FORCE(S0)
OFF	RUNNING->OFF	CALL_SCENE_FORCE(S0)
OFF	RUNNING->ON	CALL_SCENE_FORCE(S0)
OFF	RUNNING->ON (PRIO)	CALL_SCENE_FORCE(S0)
ON	OFF	CALL_SCENE_FORCE(S0)
ON	ZONE_ON	CALL_SCENE_FORCE(S0)
ON	ON	CALL_SCENE_FORCE(S0)
ON	ON (PRIO)	CALL_SCENE_FORCE(S0)
ON	PRIORITY ON	CALL_SCENE_FORCE(S0)
ON	RUNNING->PRIORITY ON	CALL_SCENE_FORCE(S0)
ON	ZONE_ON	CALL_SCENE_FORCE(S0)
ON	RUNNING->OFF	CALL_SCENE_FORCE(S0)
ON	RUNNING->ON	CALL_SCENE_FORCE(S0)
ON	RUNNING->ON (PRIO)	CALL_SCENE_FORCE(S0)
RUNNING->OFF	OFF	CALL_SCENE_FORCE(S0)
RUNNING->OFF	PRIORITY ON	CALL_SCENE_FORCE(S0)
RUNNING->ON	PRIORITY ON	CALL_SCENE_FORCE(S0)
RUNNING->ON	ZONE_ON	CALL_SCENE_FORCE(S0)

Zone-Button:

CLICK_3X/TIP_3X/CLICK_3X_UP/TIP_3X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S3)
OFF	ON	CALL_SCENE(S3)
OFF	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S3)
OFF	PRIORITY ON	CALL_SCENE(S3)
OFF	RUNNING->PRIORITY ON	STOP, CALL_SCENE(S3)
OFF	RUNNING->OFF	STOP, CALL_SCENE(S3)
OFF	RUNNING->ON	STOP, CALL_SCENE(S3)
OFF	RUNNING->ON (PRIO)	STOP, SET_LOCAL_PRIO, CALL_SCENE(S3)
ON	OFF	CALL_SCENE(S3)
ON	ZONE_ON	CALL_SCENE(S3)
ON	ON	CALL_SCENE(S3)
ON	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S3)
ON	PRIORITY ON	CALL_SCENE(S3)
ON	RUNNING->PRIORITY ON	STOP, CALL_SCENE(S3)
ON	ZONE_ON	CALL_SCENE(S3)
ON	RUNNING->OFF	STOP, CALL_SCENE(S3)
ON	RUNNING->ON	STOP, CALL_SCENE(S3)
ON	RUNNING->ON (PRIO)	STOP, SET_LOCAL_PRIO, CALL_SCENE(S3)
RUNNING->OFF	OFF	CALL_SCENE(S3)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(S3)
RUNNING->ON	PRIORITY ON	CALL_SCENE(S3)
RUNNING->ON	ZONE_ON	CALL_SCENE(S3)

Zone-Button: CLICK_3X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	ON (PRIO)	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	PRIORITY ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	RUNNING->PRIORITY ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	RUNNING->OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	RUNNING->ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	RUNNING->ON (PRIO)	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	ZONE_ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	ON (PRIO)	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	PRIORITY ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	RUNNING->PRIORITY ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	ZONE_ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	RUNNING->OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	RUNNING->ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	RUNNING->ON (PRIO)	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
RUNNING->OFF	OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
RUNNING->OFF	PRIORITY ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
RUNNING->ON	PRIORITY ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
RUNNING->ON	ZONE_ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)

Zone-Button: TIP_3X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(STANDBY)
OFF	ON	CALL_SCENE(STANDBY)
OFF	ON (PRIO)	CALL_SCENE(STANDBY)
OFF	PRIORITY ON	CALL_SCENE(STANDBY)
OFF	RUNNING->PRIORITY ON	CALL_SCENE(STANDBY)
OFF	RUNNING->OFF	CALL_SCENE(STANDBY)
OFF	RUNNING->ON	CALL_SCENE(STANDBY)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(STANDBY)
ON	OFF	CALL_SCENE(STANDBY)
ON	ZONE_ON	CALL_SCENE(STANDBY)
ON	ON	CALL_SCENE(STANDBY)
ON	ON (PRIO)	CALL_SCENE(STANDBY)
ON	PRIORITY ON	CALL_SCENE(STANDBY)
ON	RUNNING->PRIORITY ON	CALL_SCENE(STANDBY)
ON	ZONE_ON	CALL_SCENE(STANDBY)
ON	RUNNING->OFF	CALL_SCENE(STANDBY)
ON	RUNNING->ON	CALL_SCENE(STANDBY)
ON	RUNNING->ON (PRIO)	CALL_SCENE(STANDBY)
RUNNING->OFF	OFF	CALL_SCENE(STANDBY)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(STANDBY)
RUNNING->ON	PRIORITY ON	CALL_SCENE(STANDBY)
RUNNING->ON	ZONE_ON	CALL_SCENE(STANDBY)

Zone-Button: TIP_4X/TIP_4X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S4)
OFF	ON	CALL_SCENE(S4)
OFF	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S4)
OFF	PRIORITY ON	CALL_SCENE(S4)
OFF	RUNNING->PRIORITY ON	STOP, CALL_SCENE(S4)
OFF	RUNNING->OFF	STOP, CALL_SCENE(S4)
OFF	RUNNING->ON	STOP, CALL_SCENE(S4)
OFF	RUNNING->ON (PRIO)	STOP, SET_LOCAL_PRIO, CALL_SCENE(S4)
ON	OFF	CALL_SCENE(S4)
ON	ZONE_ON	CALL_SCENE(S4)
ON	ON	CALL_SCENE(S4)
ON	ON (PRIO)	SET_LOCAL_PRIO, CALL_SCENE(S4)
ON	PRIORITY ON	CALL_SCENE(S4)
ON	RUNNING->PRIORITY ON	STOP, CALL_SCENE(S4)
ON	ZONE_ON	CALL_SCENE(S4)
ON	RUNNING->OFF	STOP, CALL_SCENE(S4)
ON	RUNNING->ON	STOP, CALL_SCENE(S4)
ON	RUNNING->ON (PRIO)	STOP, SET_LOCAL_PRIO, CALL_SCENE(S4)
RUNNING->OFF	OFF	CALL_SCENE(S4)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(S4)
RUNNING->ON	PRIORITY ON	CALL_SCENE(S4)
RUNNING->ON	ZONE_ON	CALL_SCENE(S4)

Zone-Button: TIP_4X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(DEEP_OFF)
OFF	ON	CALL_SCENE(DEEP_OFF)
OFF	ON (PRIO)	CALL_SCENE(DEEP_OFF)
OFF	PRIORITY ON	CALL_SCENE(DEEP_OFF)
OFF	RUNNING->PRIORITY ON	CALL_SCENE(DEEP_OFF)
OFF	RUNNING->OFF	CALL_SCENE(DEEP_OFF)
OFF	RUNNING->ON	CALL_SCENE(DEEP_OFF)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(DEEP_OFF)
ON	OFF	CALL_SCENE(DEEP_OFF)
ON	ZONE_ON	CALL_SCENE(DEEP_OFF)
ON	ON	CALL_SCENE(DEEP_OFF)
ON	ON (PRIO)	CALL_SCENE(DEEP_OFF)
ON	PRIORITY ON	CALL_SCENE(DEEP_OFF)
ON	RUNNING->PRIORITY ON	CALL_SCENE(DEEP_OFF)
ON	ZONE_ON	CALL_SCENE(DEEP_OFF)
ON	RUNNING->OFF	CALL_SCENE(DEEP_OFF)
ON	RUNNING->ON	CALL_SCENE(DEEP_OFF)
ON	RUNNING->ON (PRIO)	CALL_SCENE(DEEP_OFF)
RUNNING->OFF	OFF	CALL_SCENE(DEEP_OFF)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(DEEP_OFF)
RUNNING->ON	PRIORITY ON	CALL_SCENE(DEEP_OFF)
RUNNING->ON	ZONE_ON	CALL_SCENE(DEEP_OFF)

Zone-Button: HOLD_START/HOLD_REPEAT

Origin Room	Area	Action
OFF	OFF	ZONE_OFF
OFF	ON	ZONE_OFF
OFF	ON (PRIO)	ZONE_OFF
OFF	PRIORITY ON	ZONE_OFF
OFF	RUNNING->PRIORITY ON	ZONE_OFF
OFF	RUNNING->OFF	ZONE_OFF
OFF	RUNNING->ON	ZONE_OFF
OFF	RUNNING->ON (PRIO)	ZONE_OFF
ON	OFF	DIMM_ZONE
ON	ZONE_ON	DIMM_ZONE
ON	ON	DIMM_ZONE
ON	ON (PRIO)	SET_LOCAL_PRIO, DIMM_ZONE
ON	PRIORITY ON	DIMM_ZONE
ON	RUNNING->PRIORITY ON	STOP, DIMM_ZONE
ON	ZONE_ON	DIMM_ZONE
ON	RUNNING->OFF	STOP, DIMM_ZONE
ON	RUNNING->ON	STOP, DIMM_ZONE
ON	RUNNING->ON (PRIO)	STOP, SET_LOCAL_PRIO, DIMM_ZONE
RUNNING->OFF	OFF	ZONE_OFF
RUNNING->OFF	PRIORITY ON	ZONE_OFF
RUNNING->ON	PRIORITY ON	(stop timer), DIMM_ZONE
RUNNING->ON	ZONE_ON	(stop timer), DIMM_ZONE

Zone-Button: HOLD_START_UP/HOLD_REPEAT_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE_MIN(S1), DIMM_ZONE
OFF	ON	CALL_SCENE_MIN(S1), DIMM_ZONE
OFF	ON (PRIO)	CALL_SCENE_MIN(S1), SET_LOCAL_PRIO, DIMM_ZONE
OFF	PRIORITY ON	CALL_SCENE_MIN(S1), DIMM_ZONE
OFF	RUNNING->PRIORITY ON	(stop timer), CALL_SCENE_MIN(S1), DIMM_ZONE
OFF	RUNNING->OFF	(stop timer), CALL_SCENE_MIN(S1), DIMM_ZONE
OFF	RUNNING->ON	(stop timer), CALL_SCENE_MIN(S1), DIMM_ZONE
OFF	RUNNING->ON (PRIO)	(stop timer), CALL_SCENE_MIN(S1), SET_LOCAL_PRIO, DIMM_ZONE
ON	OFF	DIMM_ZONE
ON	ZONE_ON	DIMM_ZONE
ON	ON	DIMM_ZONE
ON	ON (PRIO)	SET_LOCAL_PRIO, DIMM_ZONE
ON	PRIORITY ON	DIMM_ZONE
ON	RUNNING->PRIORITY ON	STOP, DIMM_ZONE
ON	ZONE_ON	DIMM_ZONE
ON	RUNNING->OFF	STOP, DIMM_ZONE
ON	RUNNING->ON	STOP, DIMM_ZONE
ON	RUNNING->ON (PRIO)	STOP, SET_LOCAL_PRIO, DIMM_ZONE
RUNNING->OFF	OFF	(stop timer), CALL_SCENE_MIN(S1), DIMM_ZONE
RUNNING->OFF	PRIORITY ON	(stop timer), CALL_SCENE_MIN(S1), DIMM_ZONE
RUNNING->ON	PRIORITY ON	(stop timer), DIMM_ZONE
RUNNING->ON	ZONE_ON	(stop timer), DIMM_ZONE

Zone-Button:
HOLD_START_DOWN/HOLD_REPEAT_DOWN

Origin Room	Area	Action
OFF	OFF	ZONE_OFF
OFF	ON	ZONE_OFF
OFF	ON (PRIO)	ZONE_OFF
OFF	PRIORITY ON	ZONE_OFF
OFF	RUNNING->PRIORITY ON	ZONE_OFF
OFF	RUNNING->OFF	ZONE_OFF
OFF	RUNNING->ON	ZONE_OFF
OFF	RUNNING->ON (PRIO)	ZONE_OFF
ON	OFF	DIMM_ZONE
ON	ZONE_ON	DIMM_ZONE
ON	ON	DIMM_ZONE
ON	ON (PRIO)	SET_LOCAL_PRIO, DIMM_ZONE
ON	PRIORITY ON	DIMM_ZONE
ON	RUNNING->PRIORITY ON	STOP, DIMM_ZONE
ON	ZONE_ON	DIMM_ZONE
ON	RUNNING->OFF	STOP, DIMM_ZONE
ON	RUNNING->ON	STOP, DIMM_ZONE
ON	RUNNING->ON (PRIO)	SET_LOCAL_PRIO, STOP, DIMM_ZONE
RUNNING->OFF	OFF	ZONE_OFF
RUNNING->OFF	PRIORITY ON	ZONE_OFF
RUNNING->ON	PRIORITY ON	(stop timer), DIMM_ZONE
RUNNING->ON	ZONE_ON	(stop timer), DIMM_ZONE

Area-Button (with LocalPrio):
CLICK_1X/TIP_1X

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(A1), [start LP timer]
OFF	ON	CALL_SCENE(A0)
OFF	ON (PRIO)	CALL_SCENE(A0)
OFF	PRIORITY ON	CALL_SCENE(A0)
OFF	RUNNING->PRIORITY ON	STOP_AREA
OFF	RUNNING->OFF	STOP_AREA
OFF	RUNNING->ON	STOP_AREA
OFF	RUNNING->ON (PRIO)	STOP_AREA
ON	OFF	CALL_SCENE(A1), [start LP timer]
ON	ZONE_ON	CALL_SCENE(A0)
ON	ON	CALL_SCENE(A0)
ON	ON (PRIO)	CALL_SCENE(A0)
ON	PRIORITY ON	CALL_SCENE(A0)
ON	RUNNING->PRIORITY ON	STOP_AREA
ON	ZONE_ON	CALL_SCENE(A0)
ON	RUNNING->OFF	STOP_AREA
ON	RUNNING->ON	STOP_AREA
ON	RUNNING->ON (PRIO)	STOP_AREA
RUNNING->OFF	OFF	STOP
RUNNING->OFF	PRIORITY ON	STOP
RUNNING->ON	PRIORITY ON	STOP
RUNNING->ON	ZONE_ON	STOP

Area-Button (with LocalPrio):
 CLICK_1X_UP/TIP_1X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(A1), (start LP timer)
OFF	ON	CALL_SCENE(A1), (start LP timer)
OFF	ON (PRIO)	CALL_SCENE(A1), (start LP timer)
OFF	PRI0 ON	CALL_SCENE(A1), (start LP timer)
OFF	RUNNING->PRI0 ON	STOP_AREA
OFF	RUNNING->OFF	STOP_AREA
OFF	RUNNING->ON	STOP_AREA
OFF	RUNNING->ON (PRIO)	STOP_AREA
ON	OFF	CALL_SCENE(A1), (start LP timer)
ON	ZONE_ON	CALL_SCENE(A1), (start LP timer)
ON	ON	CALL_SCENE(A1), (start LP timer)
ON	ON (PRIO)	CALL_SCENE(A1), (start LP timer)
ON	PRI0 ON	CALL_SCENE(A1), (start LP timer)
ON	RUNNING->PRI0 ON	STOP_AREA
ON	ZONE_ON	CALL_SCENE(A1), (start LP timer)
ON	RUNNING->OFF	STOP_AREA
ON	RUNNING->ON	STOP_AREA
ON	RUNNING->ON (PRIO)	STOP_AREA
RUNNING->OFF	OFF	STOP
RUNNING->OFF	PRI0 ON	STOP
RUNNING->ON	PRI0 ON	STOP
RUNNING->ON	ZONE_ON	STOP

Area-Button: CLICK_1X_DOWN/TIP_1X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(A0)
OFF	ON	CALL_SCENE(A0)
OFF	ON (PRIO)	CALL_SCENE(A0)
OFF	PRIORITY ON	CALL_SCENE(A0)
OFF	RUNNING->PRIORITY ON	STOP_AREA
OFF	RUNNING->OFF	STOP_AREA
OFF	RUNNING->ON	STOP_AREA
OFF	RUNNING->ON (PRIO)	STOP_AREA
ON	OFF	CALL_SCENE(A0)
ON	ZONE_ON	CALL_SCENE(A0)
ON	ON	CALL_SCENE(A0)
ON	ON (PRIO)	CALL_SCENE(A0)
ON	PRIORITY ON	CALL_SCENE(A0)
ON	RUNNING->PRIORITY ON	STOP_AREA
ON	ZONE_ON	CALL_SCENE(A0)
ON	RUNNING->OFF	STOP_AREA
ON	RUNNING->ON	STOP_AREA
ON	RUNNING->ON (PRIO)	STOP_AREA
RUNNING->OFF	OFF	STOP
RUNNING->OFF	PRIORITY ON	STOP
RUNNING->ON	PRIORITY ON	STOP
RUNNING->ON	ZONE_ON	STOP

Area-Button: CLICK_2X/TIP_2X

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S2)
OFF	ON	CALL_SCENE(S2)
OFF	ON (PRIO)	CALL_SCENE(S2)
OFF	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S2)
OFF	RUNNING->PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S2)
OFF	RUNNING->OFF	CALL_SCENE(S2)
OFF	RUNNING->ON	CALL_SCENE(S2)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(S2)
ON	OFF	CALL_SCENE(S2)
ON	ZONE_ON	CALL_SCENE(S2)
ON	ON	CALL_SCENE(S2)
ON	ON (PRIO)	CALL_SCENE(S2)
ON	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S2)
ON	RUNNING->PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S2)
ON	ZONE_ON	CALL_SCENE(S2)
ON	RUNNING->OFF	CALL_SCENE(S2)
ON	RUNNING->ON	CALL_SCENE(S2)
ON	RUNNING->ON (PRIO)	CALL_SCENE(S2)
RUNNING->OFF	OFF	CALL_SCENE(S2)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S2)
RUNNING->ON	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S2)
RUNNING->ON	ZONE_ON	CALL_SCENE(S2)

Area-Button: CLICK_2X_UP/TIP_2X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S2)
OFF	ON	CALL_SCENE(S2)
OFF	ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S2)
OFF	PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S2)
OFF	RUNNING->PRIO ON	CALL_SCENE(A0), CALL_SCENE(S2)
OFF	RUNNING->OFF	CALL_SCENE(S2)
OFF	RUNNING->ON	CALL_SCENE(S2)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S2)
ON	OFF	CALL_SCENE(S2)
ON	ZONE_ON	CALL_SCENE(S2)
ON	ON	CALL_SCENE(S2)
ON	ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S2)
ON	PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S2)
ON	RUNNING->PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S2)
ON	ZONE_ON	CALL_SCENE(S2)
ON	RUNNING->OFF	CALL_SCENE(S2)
ON	RUNNING->ON	CALL_SCENE(S2)
ON	RUNNING->ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S2)
RUNNING->OFF	OFF	CALL_SCENE(S2)
RUNNING->OFF	PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S2)
RUNNING->ON	PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S2)
RUNNING->ON	ZONE_ON	CALL_SCENE(S2)

Area-Button: CLICK_2X_DOWN/TIP_2X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE_FORCE(S0)
OFF	ON	CALL_SCENE_FORCE(S0)
OFF	ON (PRIO)	CALL_SCENE_FORCE(S0)
OFF	PRIORITY ON	CALL_SCENE_FORCE(S0)
OFF	RUNNING->PRIORITY ON	CALL_SCENE_FORCE(S0)
OFF	RUNNING->OFF	CALL_SCENE_FORCE(S0)
OFF	RUNNING->ON	CALL_SCENE_FORCE(S0)
OFF	RUNNING->ON (PRIO)	CALL_SCENE_FORCE(S0)
ON	OFF	CALL_SCENE_FORCE(S0)
ON	ZONE_ON	CALL_SCENE_FORCE(S0)
ON	ON	CALL_SCENE_FORCE(S0)
ON	ON (PRIO)	CALL_SCENE_FORCE(S0)
ON	PRIORITY ON	CALL_SCENE_FORCE(S0)
ON	RUNNING->PRIORITY ON	CALL_SCENE_FORCE(S0)
ON	ZONE_ON	CALL_SCENE_FORCE(S0)
ON	RUNNING->OFF	CALL_SCENE_FORCE(S0)
ON	RUNNING->ON	CALL_SCENE_FORCE(S0)
ON	RUNNING->ON (PRIO)	CALL_SCENE_FORCE(S0)
RUNNING->OFF	OFF	CALL_SCENE_FORCE(S0)
RUNNING->OFF	PRIORITY ON	CALL_SCENE_FORCE(S0)
RUNNING->ON	PRIORITY ON	CALL_SCENE_FORCE(S0)
RUNNING->ON	ZONE_ON	CALL_SCENE_FORCE(S0)

Area-Button: CLICK_3X/TIP_3X

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S3)
OFF	ON	CALL_SCENE(S3)
OFF	ON (PRIO)	CALL_SCENE(S3)
OFF	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S3)
OFF	RUNNING->PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S3)
OFF	RUNNING->OFF	CALL_SCENE(S3)
OFF	RUNNING->ON	CALL_SCENE(S3)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(S3)
ON	OFF	CALL_SCENE(S3)
ON	ZONE_ON	CALL_SCENE(S3)
ON	ON	CALL_SCENE(S3)
ON	ON (PRIO)	CALL_SCENE(S3)
ON	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S3)
ON	RUNNING->PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S3)
ON	ZONE_ON	CALL_SCENE(S3)
ON	RUNNING->OFF	CALL_SCENE(S3)
ON	RUNNING->ON	CALL_SCENE(S3)
ON	RUNNING->ON (PRIO)	CALL_SCENE(S3)
RUNNING->OFF	OFF	CALL_SCENE(S3)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S3)
RUNNING->ON	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S3)
RUNNING->ON	ZONE_ON	CALL_SCENE(S3)

Area-Button: CLICK_3X_UP/TIP_3X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S3)
OFF	ON	CALL_SCENE(S3)
OFF	ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S3)
OFF	PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S3)
OFF	RUNNING->PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S3)
OFF	RUNNING->OFF	CALL_SCENE(S3)
OFF	RUNNING->ON	CALL_SCENE(S3)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S3)
ON	OFF	CALL_SCENE(S3)
ON	ZONE_ON	CALL_SCENE(S3)
ON	ON	CALL_SCENE(S3)
ON	ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S3)
ON	PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S3)
ON	RUNNING->PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S3)
ON	ZONE_ON	CALL_SCENE(S3)
ON	RUNNING->OFF	CALL_SCENE(S3)
ON	RUNNING->ON	CALL_SCENE(S3)
ON	RUNNING->ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S3)
RUNNING->OFF	OFF	CALL_SCENE(S3)
RUNNING->OFF	PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S3)
RUNNING->ON	PRI0 ON	CALL_SCENE(A0), CALL_SCENE(S3)
RUNNING->ON	ZONE_ON	CALL_SCENE(S3)

Area-Button: CLICK_3X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	ON (PRIO)	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	PRI0 ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	RUNNING->PRI0 ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	RUNNING->OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	RUNNING->ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
OFF	RUNNING->ON (PRIO)	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	ZONE_ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	ON (PRIO)	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	PRI0 ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	RUNNING->PRI0 ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	ZONE_ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	RUNNING->OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	RUNNING->ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
ON	RUNNING->ON (PRIO)	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
RUNNING->OFF	OFF	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
RUNNING->OFF	PRI0 ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
RUNNING->ON	PRI0 ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)
RUNNING->ON	ZONE_ON	CALL_SCENE_FORCE(S0), CALL_SCENE(STANDBY)

Area-Button: TIP_3X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(STANDBY)
OFF	ON	CALL_SCENE(STANDBY)
OFF	ON (PRIO)	CALL_SCENE(STANDBY)
OFF	PRIORITY ON	CALL_SCENE(STANDBY)
OFF	RUNNING->PRIORITY ON	CALL_SCENE(STANDBY)
OFF	RUNNING->OFF	CALL_SCENE(STANDBY)
OFF	RUNNING->ON	CALL_SCENE(STANDBY)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(STANDBY)
ON	OFF	CALL_SCENE(STANDBY)
ON	ZONE_ON	CALL_SCENE(STANDBY)
ON	ON	CALL_SCENE(STANDBY)
ON	ON (PRIO)	CALL_SCENE(STANDBY)
ON	PRIORITY ON	CALL_SCENE(STANDBY)
ON	RUNNING->PRIORITY ON	CALL_SCENE(STANDBY)
ON	ZONE_ON	CALL_SCENE(STANDBY)
ON	RUNNING->OFF	CALL_SCENE(STANDBY)
ON	RUNNING->ON	CALL_SCENE(STANDBY)
ON	RUNNING->ON (PRIO)	CALL_SCENE(STANDBY)
RUNNING->OFF	OFF	CALL_SCENE(STANDBY)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(STANDBY)
RUNNING->ON	PRIORITY ON	CALL_SCENE(STANDBY)
RUNNING->ON	ZONE_ON	CALL_SCENE(STANDBY)

Area-Button: TIP_4X

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S4)
OFF	ON	CALL_SCENE(S4)
OFF	ON (PRIO)	CALL_SCENE(S4)
OFF	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
OFF	RUNNING->PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
OFF	RUNNING->OFF	CALL_SCENE(S4)
OFF	RUNNING->ON	CALL_SCENE(S4)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(S4)
ON	OFF	CALL_SCENE(S4)
ON	ZONE_ON	CALL_SCENE(S4)
ON	ON	CALL_SCENE(S4)
ON	ON (PRIO)	CALL_SCENE(S4)
ON	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
ON	RUNNING->PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
ON	ZONE_ON	CALL_SCENE(S4)
ON	RUNNING->OFF	CALL_SCENE(S4)
ON	RUNNING->ON	CALL_SCENE(S4)
ON	RUNNING->ON (PRIO)	CALL_SCENE(S4)
RUNNING->OFF	OFF	CALL_SCENE(S4)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
RUNNING->ON	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
RUNNING->ON	ZONE_ON	CALL_SCENE(S4)

Area-Button: TIP_4X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(S4)
OFF	ON	CALL_SCENE(S4)
OFF	ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S4)
OFF	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
OFF	RUNNING->PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
OFF	RUNNING->OFF	CALL_SCENE(S4)
OFF	RUNNING->ON	CALL_SCENE(S4)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S4)
ON	OFF	CALL_SCENE(S4)
ON	ZONE_ON	CALL_SCENE(S4)
ON	ON	CALL_SCENE(S4)
ON	ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S4)
ON	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
ON	RUNNING->PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
ON	ZONE_ON	CALL_SCENE(S4)
ON	RUNNING->OFF	CALL_SCENE(S4)
ON	RUNNING->ON	CALL_SCENE(S4)
ON	RUNNING->ON (PRIO)	CALL_SCENE(A0), CALL_SCENE(S4)
RUNNING->OFF	OFF	CALL_SCENE(S4)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
RUNNING->ON	PRIORITY ON	CALL_SCENE(A0), CALL_SCENE(S4)
RUNNING->ON	ZONE_ON	CALL_SCENE(S4)

Area-Button: TIP_4X_DOWN

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(DEEP_OFF)
OFF	ON	CALL_SCENE(DEEP_OFF)
OFF	ON (PRIO)	CALL_SCENE(DEEP_OFF)
OFF	PRIORITY ON	CALL_SCENE(DEEP_OFF)
OFF	RUNNING->PRIORITY ON	CALL_SCENE(DEEP_OFF)
OFF	RUNNING->OFF	CALL_SCENE(DEEP_OFF)
OFF	RUNNING->ON	CALL_SCENE(DEEP_OFF)
OFF	RUNNING->ON (PRIO)	CALL_SCENE(DEEP_OFF)
ON	OFF	CALL_SCENE(DEEP_OFF)
ON	ZONE_ON	CALL_SCENE(DEEP_OFF)
ON	ON	CALL_SCENE(DEEP_OFF)
ON	ON (PRIO)	CALL_SCENE(DEEP_OFF)
ON	PRIORITY ON	CALL_SCENE(DEEP_OFF)
ON	RUNNING->PRIORITY ON	CALL_SCENE(DEEP_OFF)
ON	ZONE_ON	CALL_SCENE(DEEP_OFF)
ON	RUNNING->OFF	CALL_SCENE(DEEP_OFF)
ON	RUNNING->ON	CALL_SCENE(DEEP_OFF)
ON	RUNNING->ON (PRIO)	CALL_SCENE(DEEP_OFF)
RUNNING->OFF	OFF	CALL_SCENE(DEEP_OFF)
RUNNING->OFF	PRIORITY ON	CALL_SCENE(DEEP_OFF)
RUNNING->ON	PRIORITY ON	CALL_SCENE(DEEP_OFF)
RUNNING->ON	ZONE_ON	CALL_SCENE(DEEP_OFF)

Area-Button: HOLD_START/HOLD_REPEAT

Origin Room	Area	Action
OFF	OFF	ZONE_OFF
OFF	ON	DIMM_AREA
OFF	ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
OFF	PRIORITY ON	DIMM_AREA
OFF	RUNNING->PRIORITY ON	[stop timer], DIMM_AREA
OFF	RUNNING->OFF	ZONE_OFF
OFF	RUNNING->ON	[stop timer], DIMM_AREA
OFF	RUNNING->ON (PRIO)	[stop timer], SET_LOCAL_PRIO, DIMM_AREA
ON	OFF	ZONE_OFF
ON	ZONE_ON	DIMM_AREA
ON	ON	DIMM_AREA
ON	ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
ON	PRIORITY ON	DIMM_AREA
ON	RUNNING->PRIORITY ON	[stop timer], DIMM_AREA
ON	ZONE_ON	DIMM_AREA
ON	RUNNING->OFF	ZONE_OFF
ON	RUNNING->ON	[stop timer], DIMM_AREA
ON	RUNNING->ON (PRIO)	[stop timer], SET_LOCAL_PRIO, DIMM_AREA
RUNNING->OFF	OFF	ZONE_OFF
RUNNING->OFF	PRIORITY ON	STOP, DIMM_AREA
RUNNING->ON	PRIORITY ON	STOP, DIMM_AREA
RUNNING->ON	ZONE_ON	STOP, DIMM_AREA

Area-Button: HOLD_START_UP/HOLD_REPEAT_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE_MIN(A1), DIMM_AREA
OFF	ON	DIMM_AREA
OFF	ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
OFF	PRIORITY ON	DIMM_AREA
OFF	RUNNING->PRIORITY ON	DIMM_AREA
OFF	RUNNING->OFF	CALL_SCENE_MIN(A1), DIMM_AREA
OFF	RUNNING->ON	DIMM_AREA
OFF	RUNNING->ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
ON	OFF	CALL_SCENE_MIN(A1), DIMM_AREA
ON	ZONE_ON	DIMM_AREA
ON	ON	DIMM_AREA
ON	ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
ON	PRIORITY ON	DIMM_AREA
ON	RUNNING->PRIORITY ON	DIMM_AREA
ON	ZONE_ON	DIMM_AREA
ON	RUNNING->OFF	CALL_SCENE_MIN(A1), DIMM_AREA
ON	RUNNING->ON	DIMM_AREA
ON	RUNNING->ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
RUNNING->OFF	OFF	CALL_SCENE_MIN(A1), DIMM_AREA
RUNNING->OFF	PRIORITY ON	STOP, DIMM_AREA
RUNNING->ON	PRIORITY ON	STOP, DIMM_AREA
RUNNING->ON	ZONE_ON	DIMM_AREA

Area-Button:
HOLD_START_DOWN/HOLD_REPEAT_DOWN

Origin Room	Area	Action
OFF	OFF	ZONE_OFF
OFF	ON	DIMM_AREA
OFF	ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
OFF	PRIORITY ON	DIMM_AREA
OFF	RUNNING->PRIORITY ON	DIMM_AREA
OFF	RUNNING->OFF	ZONE_OFF
OFF	RUNNING->ON	DIMM_AREA
OFF	RUNNING->ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
ON	OFF	ZONE_OFF
ON	ZONE_ON	DIMM_AREA
ON	ON	DIMM_AREA
ON	ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
ON	PRIORITY ON	DIMM_AREA
ON	RUNNING->PRIORITY ON	DIMM_AREA
ON	ZONE_ON	DIMM_AREA
ON	RUNNING->OFF	ZONE_OFF
ON	RUNNING->ON	DIMM_AREA
ON	RUNNING->ON (PRIO)	SET_LOCAL_PRIO, DIMM_AREA
RUNNING->OFF	OFF	ZONE_OFF
RUNNING->OFF	PRIORITY ON	STOP, DIMM_AREA
RUNNING->ON	PRIORITY ON	STOP, DIMM_AREA
RUNNING->ON	ZONE_ON	DIMM_AREA

Local Prio timeout

Origin Room	Area	Action
OFF	OFF	
OFF	ON	
OFF	ON (PRIO)	SET_LOCAL_PRIO
OFF	PRI0 ON	
OFF	RUNNING->PRI0 ON	
OFF	RUNNING->OFF	
OFF	RUNNING->ON	
OFF	RUNNING->ON (PRIO)	SET_LOCAL_PRIO
ON	OFF	
ON	ZONE_ON	
ON	ON	
ON	ON (PRIO)	SET_LOCAL_PRIO
ON	PRI0 ON	
ON	RUNNING->PRI0 ON	
ON	ZONE_ON	
ON	RUNNING->OFF	
ON	RUNNING->ON	
ON	RUNNING->ON (PRIO)	SET_LOCAL_PRIO
RUNNING->OFF	OFF	
RUNNING->OFF	PRI0 ON	
RUNNING->ON	PRI0 ON	
RUNNING->ON	ZONE_ON	

Area-Button (no LocalPrio): CLICK_1X/TIP_1X

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(A1)
OFF	ON	CALL_SCENE(A0)
OFF	ON (PRIO)	CALL_SCENE(A0)
OFF	PRIORITY ON	CALL_SCENE(A0)
OFF	RUNNING->PRIORITY ON	STOP_AREA
OFF	RUNNING->OFF	STOP_AREA
OFF	RUNNING->ON	STOP_AREA
OFF	RUNNING->ON (PRIO)	STOP_AREA
ON	OFF	CALL_SCENE(A1)
ON	ZONE_ON	CALL_SCENE(A0)
ON	ON	CALL_SCENE(A0)
ON	ON (PRIO)	CALL_SCENE(A0)
ON	PRIORITY ON	CALL_SCENE(A0)
ON	RUNNING->PRIORITY ON	STOP_AREA
ON	ZONE_ON	CALL_SCENE(A0)
ON	RUNNING->OFF	STOP_AREA
ON	RUNNING->ON	STOP_AREA
ON	RUNNING->ON (PRIO)	STOP_AREA
RUNNING->OFF	OFF	STOP
RUNNING->OFF	PRIORITY ON	STOP
RUNNING->ON	PRIORITY ON	STOP
RUNNING->ON	ZONE_ON	STOP

Area-Button (no LocalPrio):
 CLICK_1X_UP/TIP_1X_UP

Origin Room	Area	Action
OFF	OFF	CALL_SCENE(A1)
OFF	ON	CALL_SCENE(A1)
OFF	ON (PRIO)	CALL_SCENE(A1)
OFF	PRI0 ON	CALL_SCENE(A1)
OFF	RUNNING->PRI0 ON	STOP_AREA
OFF	RUNNING->OFF	STOP_AREA
OFF	RUNNING->ON	STOP_AREA
OFF	RUNNING->ON (PRIO)	STOP_AREA
ON	OFF	CALL_SCENE(A1)
ON	ZONE_ON	CALL_SCENE(A1)
ON	ON	CALL_SCENE(A1)
ON	ON (PRIO)	CALL_SCENE(A1)
ON	PRI0 ON	CALL_SCENE(A1)
ON	RUNNING->PRI0 ON	STOP_AREA
ON	ZONE_ON	CALL_SCENE(A1)
ON	RUNNING->OFF	STOP_AREA
ON	RUNNING->ON	STOP_AREA
ON	RUNNING->ON (PRIO)	STOP_AREA
RUNNING->OFF	OFF	STOP
RUNNING->OFF	PRI0 ON	STOP
RUNNING->ON	PRI0 ON	STOP
RUNNING->ON	ZONE_ON	STOP

State Transitions

CALL_SCENE(S0)

Origin Room	Area	Destination Room	Area
OFF	OFF	RUNNING->OFF	OFF
OFF	ON	RUNNING->OFF	OFF
OFF	ON (PRIO)	RUNNING->OFF	OFF
OFF	PRI0 ON	RUNNING->OFF	PRI0 ON
OFF	RUNNING->PRI0 ON	RUNNING->OFF	RUNNING->ON PRI0
OFF	RUNNING->OFF	RUNNING->OFF	OFF
OFF	RUNNING->ON	RUNNING->OFF	OFF
OFF	RUNNING->ON (PRIO)	RUNNING->OFF	OFF
ON	OFF	RUNNING->OFF	OFF
ON	ZONE_ON	RUNNING->OFF	OFF
ON	ON	RUNNING->OFF	OFF
ON	ON (PRIO)	RUNNING->OFF	OFF
ON	PRI0 ON	RUNNING->OFF	PRI0 ON
ON	RUNNING->PRI0 ON	RUNNING->OFF	RUNNING->ON PRI0
ON	ZONE_ON	RUNNING->OFF	OFF
ON	RUNNING->OFF	RUNNING->OFF	OFF
ON	RUNNING->ON	RUNNING->OFF	OFF
ON	RUNNING->ON (PRIO)	RUNNING->OFF	OFF
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRI0 ON	RUNNING->OFF	PRI0 ON
RUNNING->ON	PRI0 ON	RUNNING->OFF	PRI0 ON
RUNNING->ON	ZONE_ON	RUNNING->OFF	OFF

CALL_SCENE(S1-S4)

Origin Room	Area	Destination Room	Area
OFF	OFF	RUNNING->ON	ZONE_ON
OFF	ON	RUNNING->ON	ZONE_ON
OFF	ON (PRIO)	RUNNING->ON	ZONE_ON
OFF	PRI0 ON	RUNNING->ON	PRI0 ON
OFF	RUNNING->PRI0 ON	RUNNING->ON	ON PRI0
OFF	RUNNING->OFF	RUNNING->ON	ZONE_ON
OFF	RUNNING->ON	RUNNING->ON	ZONE_ON
OFF	RUNNING->ON (PRIO)	RUNNING->ON	ZONE_ON
ON	OFF	RUNNING->ON	ZONE_ON
ON	ZONE_ON	RUNNING->ON	ZONE_ON
ON	ON	RUNNING->ON	ZONE_ON
ON	ON (PRIO)	RUNNING->ON	ZONE_ON
ON	PRI0 ON	RUNNING->ON	PRI0 ON
ON	RUNNING->PRI0 ON	RUNNING->ON	RUNNING->ON PRI0
ON	ZONE_ON	RUNNING->ON	ZONE_ON
ON	RUNNING->OFF	RUNNING->ON	ZONE_ON
ON	RUNNING->ON	RUNNING->ON	ZONE_ON
ON	RUNNING->ON (PRIO)	RUNNING->ON	ZONE_ON
RUNNING->OFF	OFF	RUNNING->ON	ZONE_ON
RUNNING->OFF	PRI0 ON	RUNNING->ON	PRI0 ON
RUNNING->ON	PRI0 ON	RUNNING->ON	PRI0 ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

STOP

Origin Room	Area	Destination Room	Area
OFF	OFF	OFF	OFF
OFF	ON	OFF	ON
OFF	ON (PRIO)	OFF	ON (PRIO)
OFF	PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->OFF	OFF	OFF
OFF	RUNNING->ON	OFF	ON
OFF	RUNNING->ON (PRIO)	OFF	ON (PRIO)
ON	OFF	ON	OFF
ON	ZONE_ON	ON	ZONE_ON
ON	ON	ON	ON
ON	ON (PRIO)	ON	ON (PRIO)
ON	PRI0 ON	ON	PRI0 ON
ON	RUNNING->PRI0 ON	ON	PRI0 ON
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	OFF
ON	RUNNING->ON	ON	ON
ON	RUNNING->ON (PRIO)	ON	ON (PRIO)
RUNNING->OFF	OFF	OFF	OFF
RUNNING->OFF	PRI0 ON	OFF	PRI0 ON
RUNNING->ON	PRI0 ON	ON	PRI0 ON
RUNNING->ON	ZONE_ON	ON	ZONE_ON

CALL_SCENE(A0)

Origin Room	Area	Destination Room	Area
OFF	OFF	OFF	RUNNING->OFF
OFF	ON	OFF	RUNNING->OFF
OFF	ON (PRIO)	OFF	RUNNING->OFF
OFF	PRIORITY ON	OFF	RUNNING->OFF
OFF	RUNNING->PRIORITY ON	OFF	RUNNING->OFF
OFF	RUNNING->OFF	OFF	RUNNING->OFF
OFF	RUNNING->ON	OFF	RUNNING->OFF
OFF	RUNNING->ON (PRIO)	OFF	RUNNING->OFF
ON	OFF	ON	RUNNING->OFF
ON	ZONE_ON	ON	RUNNING->OFF
ON	ON	ON	RUNNING->OFF
ON	ON (PRIO)	ON	RUNNING->OFF
ON	PRIORITY ON	ON	RUNNING->OFF
ON	RUNNING->PRIORITY ON	ON	RUNNING->OFF
ON	ZONE_ON	ON	RUNNING->OFF
ON	RUNNING->OFF	ON	RUNNING->OFF
ON	RUNNING->ON	ON	RUNNING->OFF
ON	RUNNING->ON (PRIO)	ON	RUNNING->OFF
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRIORITY ON	RUNNING->OFF	OFF
RUNNING->ON	PRIORITY ON	RUNNING->ON	OFF
RUNNING->ON	ZONE_ON	RUNNING->ON	OFF

CALL_SCENE(A1)

Origin Room	Area	Destination Room	Area
OFF	OFF	OFF	RUNNING->ON
OFF	ON	OFF	RUNNING->ON
OFF	ON (PRIO)	OFF	RUNNING->ON
OFF	PRI0 ON	OFF	RUNNING->ON ^a
OFF	RUNNING->PRI0 ON	OFF	RUNNING->ON PRIO
OFF	RUNNING->OFF	OFF	RUNNING->ON
OFF	RUNNING->ON	OFF	RUNNING->ON
OFF	RUNNING->ON (PRIO)	OFF	RUNNING->ON
ON	OFF	ON	RUNNING->ON
ON	ZONE_ON	ON	RUNNING->ON
ON	ON	ON	RUNNING->ON
ON	ON (PRIO)	ON	RUNNING->ON
ON	PRI0 ON	OFF	RUNNING->ON ^b
ON	RUNNING->PRI0 ON	ON	RUNNING->ON PRIO
ON	ZONE_ON	ON	RUNNING->ON
ON	RUNNING->OFF	ON	RUNNING->ON
ON	RUNNING->ON	ON	RUNNING->ON
ON	RUNNING->ON (PRIO)	ON	RUNNING->ON
RUNNING->OFF	OFF	RUNNING->OFF	RUNNING->ON
RUNNING->OFF	PRI0 ON	RUNNING->OFF	PRI0 ON
RUNNING->ON	PRI0 ON	RUNNING->ON	PRI0 ON
RUNNING->ON	ZONE_ON	RUNNING->ON	RUNNING->ON

^ano RUNNING-> when called from ds485

^bno RUNNING-> when called from ds485

STOP_AREA

Origin Room	Area	Destination Room	Area
OFF	OFF	OFF	OFF
OFF	ON	OFF	ON
OFF	ON (PRIO)	OFF	ON (PRIO)
OFF	PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->PRI0 ON	OFF	ON PRI0
OFF	RUNNING->OFF	OFF	OFF
OFF	RUNNING->ON	OFF	ON
OFF	RUNNING->ON (PRIO)	OFF	ON (PRIO)
ON	OFF	ON	OFF
ON	ZONE_ON	ON	ZONE_ON
ON	ON	ON	ON
ON	ON (PRIO)	ON	ON (PRIO)
ON	PRI0 ON	ON	PRI0 ON
ON	RUNNING->PRI0 ON	ON	ON PRI0
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	OFF
ON	RUNNING->ON	ON	ON
ON	RUNNING->ON (PRIO)	ON	ON (PRIO)
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRI0 ON	RUNNING->OFF	PRI0 ON
RUNNING->ON	PRI0 ON	RUNNING->ON	PRI0 ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

CALL_SCENE_FORCE(S0)
 CALL_SCENE(STANDBY)
 CALL_SCENE(DEEP_OFF)

Origin Room	Area	Destination Room	Area
OFF	OFF	RUNNING->OFF	OFF
OFF	ON	RUNNING->OFF	OFF
OFF	ON (PRIO)	RUNNING->OFF	OFF
OFF	PRI0 ON	RUNNING->OFF	OFF
OFF	RUNNING->PRI0 ON	RUNNING->OFF	OFF
OFF	RUNNING->OFF	RUNNING->OFF	OFF
OFF	RUNNING->ON	RUNNING->OFF	OFF
OFF	RUNNING->ON (PRIO)	RUNNING->OFF	OFF
ON	OFF	RUNNING->OFF	OFF
ON	ZONE_ON	RUNNING->OFF	OFF
ON	ON	RUNNING->OFF	OFF
ON	ON (PRIO)	RUNNING->OFF	OFF
ON	PRI0 ON	RUNNING->OFF	OFF
ON	RUNNING->PRI0 ON	RUNNING->OFF	OFF
ON	ZONE_ON	RUNNING->OFF	OFF
ON	RUNNING->OFF	RUNNING->OFF	OFF
ON	RUNNING->ON	RUNNING->OFF	OFF
ON	RUNNING->ON (PRIO)	RUNNING->OFF	OFF
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRI0 ON	RUNNING->OFF	OFF
RUNNING->ON	PRI0 ON	RUNNING->OFF	OFF
RUNNING->ON	ZONE_ON	RUNNING->OFF	OFF

CALL_SCENE_FORCE(S1-S4)

Origin Room	Area	Destination Room	Area
OFF	OFF	RUNNING->ON	ZONE_ON
OFF	ON	RUNNING->ON	ZONE_ON
OFF	ON (PRIO)	RUNNING->ON	ZONE_ON
OFF	PRIORITY ON	RUNNING->ON	ZONE_ON
OFF	RUNNING->PRIORITY ON	RUNNING->ON	ZONE_ON
OFF	RUNNING->OFF	RUNNING->ON	ZONE_ON
OFF	RUNNING->ON	RUNNING->ON	ZONE_ON
OFF	RUNNING->ON (PRIO)	RUNNING->ON	ZONE_ON
ON	OFF	RUNNING->ON	ZONE_ON
ON	ZONE_ON	RUNNING->ON	ZONE_ON
ON	ON	RUNNING->ON	ZONE_ON
ON	ON (PRIO)	RUNNING->ON	ZONE_ON
ON	PRIORITY ON	RUNNING->ON	ZONE_ON
ON	RUNNING->PRIORITY ON	RUNNING->ON	ZONE_ON
ON	ZONE_ON	RUNNING->ON	ZONE_ON
ON	RUNNING->OFF	RUNNING->ON	ZONE_ON
ON	RUNNING->ON	RUNNING->ON	ZONE_ON
ON	RUNNING->ON (PRIO)	RUNNING->ON	ZONE_ON
RUNNING->OFF	OFF	RUNNING->ON	ZONE_ON
RUNNING->OFF	PRIORITY ON	RUNNING->ON	ZONE_ON
RUNNING->ON	PRIORITY ON	RUNNING->ON	ZONE_ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

CALL_SCENE_FORCE(A0)

Origin Room	Area	Destination Room	Area
OFF	OFF	RUNNING->OFF	OFF
OFF	ON	RUNNING->OFF	OFF
OFF	ON (PRIO)	RUNNING->OFF	OFF
OFF	PRI0 ON	RUNNING->OFF	OFF
OFF	RUNNING->PRI0 ON	RUNNING->OFF	OFF
OFF	RUNNING->OFF	RUNNING->OFF	OFF
OFF	RUNNING->ON	RUNNING->OFF	OFF
OFF	RUNNING->ON (PRIO)	RUNNING->OFF	OFF
ON	OFF	RUNNING->OFF	OFF
ON	ZONE_ON	RUNNING->OFF	OFF
ON	ON	RUNNING->OFF	OFF
ON	ON (PRIO)	RUNNING->OFF	OFF
ON	PRI0 ON	RUNNING->OFF	OFF
ON	RUNNING->PRI0 ON	RUNNING->OFF	OFF
ON	ZONE_ON	RUNNING->OFF	OFF
ON	RUNNING->OFF	RUNNING->OFF	OFF
ON	RUNNING->ON	RUNNING->OFF	OFF
ON	RUNNING->ON (PRIO)	RUNNING->OFF	OFF
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRI0 ON	RUNNING->OFF	OFF
RUNNING->ON	PRI0 ON	RUNNING->OFF	OFF
RUNNING->ON	ZONE_ON	RUNNING->OFF	OFF

CALL_SCENE_FORCE(A1)

Origin Room	Area	Destination Room	Area
OFF	OFF	RUNNING->ON	ZONE_ON
OFF	ON	RUNNING->ON	ZONE_ON
OFF	ON (PRIO)	RUNNING->ON	ZONE_ON
OFF	PRIORITY ON	RUNNING->ON	ZONE_ON
OFF	RUNNING->PRIORITY ON	RUNNING->ON	ZONE_ON
OFF	RUNNING->OFF	RUNNING->ON	ZONE_ON
OFF	RUNNING->ON	RUNNING->ON	ZONE_ON
OFF	RUNNING->ON (PRIO)	RUNNING->ON	ZONE_ON
ON	OFF	RUNNING->ON	ZONE_ON
ON	ZONE_ON	RUNNING->ON	ZONE_ON
ON	ON	RUNNING->ON	ZONE_ON
ON	ON (PRIO)	RUNNING->ON	ZONE_ON
ON	PRIORITY ON	RUNNING->ON	ZONE_ON
ON	RUNNING->PRIORITY ON	RUNNING->ON	ZONE_ON
ON	ZONE_ON	RUNNING->ON	ZONE_ON
ON	RUNNING->OFF	RUNNING->ON	ZONE_ON
ON	RUNNING->ON	RUNNING->ON	ZONE_ON
ON	RUNNING->ON (PRIO)	RUNNING->ON	ZONE_ON
RUNNING->OFF	OFF	RUNNING->ON	ZONE_ON
RUNNING->OFF	PRIORITY ON	RUNNING->ON	ZONE_ON
RUNNING->ON	PRIORITY ON	RUNNING->ON	ZONE_ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

SET_LOCAL_PRIO(A1)

Origin Room	Area	Destination Room	Area
OFF	OFF	OFF	OFF
OFF	ON	OFF	PRIORITY ON
OFF	ON (PRIORITY)	OFF	PRIORITY ON
OFF	PRIORITY ON	OFF	PRIORITY ON
OFF	RUNNING->PRIORITY ON	OFF	RUNNING->ON PRIORITY
OFF	RUNNING->OFF	OFF	RUNNING->OFF
OFF	RUNNING->ON	OFF	RUNNING->PRIORITY ON
OFF	RUNNING->ON (PRIORITY)	OFF	RUNNING->PRIORITY ON
ON	OFF	ON	OFF
ON	ZONE_ON	ON	ZONE_ON
ON	ON	ON	PRIORITY ON
ON	ON (PRIORITY)	ON	PRIORITY ON
ON	PRIORITY ON	ON	PRIORITY ON
ON	RUNNING->PRIORITY ON	ON	RUNNING->ON PRIORITY
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	RUNNING->OFF
ON	RUNNING->ON	ON	RUNNING->PRIORITY ON
ON	RUNNING->ON (PRIORITY)	ON	RUNNING->PRIORITY ON
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRIORITY ON	RUNNING->OFF	PRIORITY ON
RUNNING->ON	PRIORITY ON	RUNNING->ON	PRIORITY ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

DIMM_ZONE

Only for events triggered through button clicks. Events triggered through ds485 do not change the internal state.

Origin		Destination	
Room	Area	Room	Area
OFF	OFF	OFF	OFF
OFF	ON	OFF	ON
OFF	ON (PRIO)	OFF	ON (PRIO)
OFF	PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->PRI0 ON	OFF	RUNNING->PRI0 ON
OFF	RUNNING->OFF	OFF	RUNNING->OFF
OFF	RUNNING->ON	OFF	RUNNING->ON
OFF	RUNNING->ON (PRIO)	OFF	RUNNING->ON (PRIO)
ON	OFF	ON	OFF
ON	ZONE_ON	ON	ZONE_ON
ON	ON	ON	ON
ON	ON (PRIO)	ON	ON (PRIO)
ON	PRI0 ON	ON	PRI0 ON
ON	RUNNING->PRI0 ON	ON	RUNNING->PRI0 ON
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	RUNNING->OFF
ON	RUNNING->ON	ON	RUNNING->ON
ON	RUNNING->ON (PRIO)	ON	RUNNING->ON (PRIO)
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRI0 ON	RUNNING->OFF	PRI0 ON
RUNNING->ON	PRI0 ON	RUNNING->ON	PRI0 ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

DIMM_AREA

Only for events triggered through button clicks. Events triggered through ds485 do not change the internal state.

Origin Room	Area	Destination Room	Area
OFF	OFF	OFF	OFF
OFF	ON	OFF	ON
OFF	ON (PRIO)	OFF	ON (PRIO)
OFF	PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->OFF	OFF	OFF
OFF	RUNNING->ON	OFF	ON
OFF	RUNNING->ON (PRIO)	OFF	ON (PRIO)
ON	OFF	ON	OFF
ON	ZONE_ON	ON	ZONE_ON
ON	ON	ON	ON
ON	ON (PRIO)	ON	ON (PRIO)
ON	PRI0 ON	ON	PRI0 ON
ON	RUNNING->PRI0 ON	ON	PRI0 ON
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	OFF
ON	RUNNING->ON	ON	ON
ON	RUNNING->ON (PRIO)	ON	ON (PRIO)
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRI0 ON	RUNNING->OFF	PRI0 ON
RUNNING->ON	PRI0 ON	RUNNING->ON	PRI0 ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

CALL_SCENE_MIN(S1-S4)

Only for events triggered through button clicks. Events triggered through ds485 do not change the internal state.

Origin		Destination	
Room	Area	Room	Area
OFF	OFF	ON	ZONE_ON
OFF	ON	ON	ZONE_ON
OFF	ON (PRIO)	ON	PRIORITY ON
OFF	PRIORITY ON	ON	PRIORITY ON
OFF	RUNNING->PRIORITY ON	ON	RUNNING->PRIORITY ON
OFF	RUNNING->OFF	ON	ZONE_ON
OFF	RUNNING->ON	ON	ZONE_ON
OFF	RUNNING->ON (PRIO)	ON	RUNNING->ON (PRIO)
ON	OFF	ON	OFF
ON	ZONE_ON	ON	ZONE_ON
ON	ON	ON	ON
ON	ON (PRIO)	ON	ON (PRIO)
ON	PRIORITY ON	ON	PRIORITY ON
ON	RUNNING->PRIORITY ON	ON	RUNNING->PRIORITY ON
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	RUNNING->OFF
ON	RUNNING->ON	ON	RUNNING->ON
ON	RUNNING->ON (PRIO)	ON	RUNNING->ON (PRIO)
RUNNING->OFF	OFF	ON	ZONE_ON
RUNNING->OFF	PRIORITY ON	ON	PRIORITY ON
RUNNING->ON	PRIORITY ON	RUNNING->ON	PRIORITY ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

CALL_SCENE_MIN(A1)

Only for events triggered through button clicks. Events triggered through ds485 do not change the internal state.

Origin		Destination	
Room	Area	Room	Area
OFF	OFF	OFF	ON
OFF	ON	OFF	ON
OFF	ON (PRIO)	OFF	ON (PRIO) ^a
OFF	PRIORITY ON	OFF	PRIORITY ON
OFF	RUNNING->PRIORITY ON	OFF	RUNNING->PRIORITY ON
OFF	RUNNING->OFF	OFF	ON
OFF	RUNNING->ON	OFF	RUNNING->ON
OFF	RUNNING->ON (PRIO)	OFF	RUNNING->ON (PRIO) ^b
ON	OFF	ON	ON
ON	ZONE_ON	ON	ON
ON	ON	ON	ON
ON	ON (PRIO)	ON	ON (PRIO) ^c
ON	PRIORITY ON	ON	PRIORITY ON
ON	RUNNING->PRIORITY ON	ON	RUNNING->PRIORITY ON
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	ON
ON	RUNNING->ON	ON	RUNNING->ON
ON	RUNNING->ON (PRIO)	ON	RUNNING->ON (PRIO) ^d
RUNNING->OFF	OFF	RUNNING->OFF	ON
RUNNING->OFF	PRIORITY ON	RUNNING->OFF	PRIORITY ON
RUNNING->ON	PRIORITY ON	RUNNING->ON	PRIORITY ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON

^aright now: ON

^bright now: RUNNING->ON

^cright now: ON

^dright now: RUNNING->ON

STOP timeout/(stop timer)

Origin Room	Area	Destination Room	Area
OFF	OFF	OFF	OFF
OFF	ON	OFF	ON
OFF	ON (PRIO)	OFF	ON (PRIO)
OFF	PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->OFF	OFF	OFF
OFF	RUNNING->ON	OFF	ON
OFF	RUNNING->ON (PRIO)	OFF	ON (PRIO)
ON	OFF	ON	OFF
ON	ZONE_ON	ON	ON
ON	ON	ON	ON
ON	ON (PRIO)	ON	ON (PRIO)
ON	PRI0 ON	ON	PRI0 ON
ON	RUNNING->PRI0 ON	ON	PRI0 ON
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	OFF
ON	RUNNING->ON	ON	ON
ON	RUNNING->ON (PRIO)	ON	ON (PRIO)
RUNNING->OFF	OFF	OFF	OFF
RUNNING->OFF	PRI0 ON	OFF	PRI0 ON
RUNNING->ON	PRI0 ON	ON	PRI0 ON
RUNNING->ON	ZONE_ON	ON	ZONE_ON

(start LP timer)

Origin Room	Area	Destination Room	Area
OFF	OFF	OFF	OFF
OFF	ON	OFF	ON (PRIO)
OFF	ON (PRIO)	OFF	ON (PRIO)
OFF	PRI0 ON	OFF	PRI0 ON
OFF	RUNNING->PRI0 ON	OFF	RUNNING->PRI0 ON
OFF	RUNNING->OFF	OFF	RUNNING->OFF
OFF	RUNNING->ON	OFF	RUNNING->ON (PRIO)
OFF	RUNNING->ON (PRIO)	OFF	RUNNING->ON (PRIO)
ON	OFF	ON	OFF
ON	ZONE_ON	ON	ZONE_ON
ON	ON	ON	ON (PRIO)
ON	ON (PRIO)	ON	ON (PRIO)
ON	PRI0 ON	ON	PRI0 ON
ON	RUNNING->PRI0 ON	ON	RUNNING->PRI0 ON
ON	ZONE_ON	ON	ZONE_ON
ON	RUNNING->OFF	ON	RUNNING->OFF
ON	RUNNING->ON	ON	RUNNING->ON (PRIO)
ON	RUNNING->ON (PRIO)	ON	RUNNING->ON (PRIO)
RUNNING->OFF	OFF	RUNNING->OFF	OFF
RUNNING->OFF	PRI0 ON	RUNNING->OFF	PRI0 ON
RUNNING->ON	PRI0 ON	RUNNING->ON	PRI0 ON
RUNNING->ON	ZONE_ON	RUNNING->ON	ZONE_ON